

1L	1R	2L	2R	3L	3R	4L	4R	5L	5R	6L	6R

7L	7R	8L	8R	9L	9R	10L	10R	11L	11R	12L	12R
						1	2				
						3	4				

						1	2				
13L	13R	14L	14R	15L	15R	16L	16R	17L	17R	18L	18R
						3	4				
						5	6	WORK LIGHTS ON	WORK LIGHTS OFF		

						1	2				
19L	19R	20L	20R	21L	21R	22L	22R	23L	23R	24L	24R
						3	4				
						WATER ON	WATER OFF				

		TIP UP	TIP DOWN			YOKE OPEN	YOKE CLOSE				
25L	25R	26L	26R	27L	27R	28L	28R	29L	29R	30L	30R
		REAVE IN	REAVE OUT			BACK BAR UP	BACK BAR DOWN				
						BELLY BAND DOWN	BELLY BAND UP				

UP	DOWN										
31L	31R	32L	32R	33L	33R	34L	34R	35L	35R	36L	36R
IN	OUT										
ENG ON	ENG OFF					PUMP ON	PUMP OFF			CLAMP	RELEASE

WATER ON	WATER OFF	RPM RPM RPM	RPM RPM RPM			FLOW DIVIDER				MAST	MAST
37L	37R	38L	38R	39L	39R	40L	40R	41L	41R	42L	42R
REEL IN	REEL OUT	STOP	GO			PROP FORWARD	PROP REVERSE				
		HORN	TRACTOR OFF			STEER LEFT	STEER RIGHT				

		FRONT AXLES LEFT	FRONT AXLES RIGHT					EXTEND	RETRACT	EXTEND	RETRACT
43L	43R	44L	44R	45L	45R	46L	46R	47L	47R	48L	48R
		MID AXLES LEFT	MID AXLES RIGHT			AXLE	AXLE	TORQUE	DE TORQUE	TORQUE	PUMP
		REAR AXLES LEFT	REAR AXLES RIGHT			DECK	DECK	PUMP		TAILSTOCK EXTEND	TAILSTOCK RETRACT

BOOM LIFT	BOOM LOWER	FLOAT	WORK LIGHTS					MAST RAISE	MAST LOWER		
73L	73R	74L	74R	75L	75R	76L	76R	77L	77R	78L	78R
SWING CCW	SWING CW	LOAD	UNLOAD					LOCK PIN IN	LOCK PIN OUT		
FLOOR ON	DIS-CHARGE ON	SQUEEZE	RELEASE					MAST LOCK	MAST UNLOCK		

		BOOM ON	BOOM OFF	UP	DOWN			BOOM UP	BOOM DOWN		
79L	79R	80L	80R	81L	81R	82L	82R	83L	83R	84L	84R
OPEN	CLOSE	ROLL OVER LEFT	ROLL OVER RIGHT	OPEN	CLOSE			BOOM IN	BOOM OUT		
		IDLE HIGH	IDLE LOW	LOCK ON	LOCK OFF			BOOM LEFT	BOOM RIGHT		

				START STOP	LIGHTS ON/OFF			YOKE CLOSE	YOKE OPEN		
85L	85R	86L	86R	87L	87R	88L	88R	89L	89R	90L	90R
								BELLY UP	BELLY DOWN		
								LIFT UP	LIFT DOWN		

		OPEN	CLOSE								
91L	91R	92L	92R	93L	93R	94L	94R	95L	95R	96L	96R
		BELLY BAND UP	BELLY BAND DOWN								
		BACK BAR DOWN	BACK BAR UP								

		UP	DOWN								
97L	97R	98L	98R	99L	99R	100L	100R	101L	101R	102L	102R
		1	2	JACKS UP	JACKS DOWN						
		3	4								

								CANOPY OPEN	CANOPY CLOSE		
103L	103R	104L	104R	105L	105R	106L	106R	107L	107R	108L	108R

				L	R					HYDRAULIC JACK UP	HYDRAULIC JACK DOWN
109L	109R	110L	110R	111L	111R	112L	112R	113L	113R	114L	114R
		BACK BAR DOWN	BACK BAR UP							HYDRAULIC JACK UP	HYDRAULIC JACK DOWN
		BELLY BAND UP	BELLY BAND DOWN		ENGINE START	OPEN DOOR	CLOSE DOOR			WINCH IN	WINCH OUT

						YOKE OPEN	YOKE CLOSE				
115L	115R	116L	116R	117L	117R	118L	118R	119L	119R	120L	120R
						GATE 1 OPEN	GATE 1 CLOSE				
						GATE 2 OPEN	GATE 2 CLOSE			DOOR OPEN	DOOR CLOSE

WINCH IN	WINCH OUT			Feeder & Discharge Start	Feeder & Discharge Stop	THROTTLE UP	THROTTLE DOWN	ENGINE START	ENGINE STOP	OPEN OUT	CLOSE IN
121L	121R	122L	122R	123L	123R	124L	124R	125L	125R	126L	126R
BODY UP	BODY DOWN			Feeder + Speed	Feeder - Speed	TUB START	TUB STOP	SPEED INCREASE	SPEED DECREASE	DOWN	UP
DOOR UP	DOOR DOWN			Hyd Unit Start	Hyd Unit Stop	TUB FORWARD	TUB REVERSE	CHOCK	DUMP VALVE	A	B

		Feeder Start	Feeder Stop			WINCH IN	WINCH OUT	Front Gate OPEN	Front Gate CLOSED		
127L	127R	128L	128R	129L	129R	130L	130R	131L	131R	132L	132R
		+ Speed	- Speed			DECK 1	DECK 1	Belly Band UP	Belly Band DOWN	Belly Band UP	Belly Band DOWN
		Hyd Unit Start	Hyd Unit Stop			DECK 2	DECK 2	Rump Bar CLOSE	Rump Bar OPEN	Back Bar DOWN	Back Bar UP

								UP	DOWN		
133L	133R	134L	134R	135L	135R	136L	136R	137L	137R	138L	138R
PTO START/STOP		CONV I	CONV O					IN	OUT	A↓ BOOM	A↑ BOOM
THROTTLE DOWN	THROTTLE UP	VIB I	VIB O					IN	OUT		

WINCH IN	WINCH OUT			Pump OFF	Pump ON	5	6	UNLOCK	LOCK	Etuaura Ylös	Etuaura Alas
139L	139R	140L	140R	141L	141R	142L	142R	143L	143R	144L	144R
				Inlet Valve OFF	Inlet Valve ON	3	4			Sivuaura Ylös	Sivuaura Alas
				Engine Speed DOWN	Engine Speed UP	2	1			Paine Pois	Paine Pois

				TOP WINCH IN	TOP WINCH OUT					Rear OUT	Front OUT
145L	145R	146L	146R	147L	147R	148L	148R	149L	149R	150L	150R
				LOWER WINCH IN	LOWER WINCH OUT					Rear FREE	Front FREE
		CLAMP	RELEASE	DECK	DECK					Rear IN	Front IN

		TOP WINCH IN	TOP WINCH OUT			Top Deck UP	Top Deck DOWN	Cover Roll OFF	Cover Roll ON	Coiling UP	Uncoiling
151L	151R	152L	152R	153L	153R	154L	154R	155L	155R	156L	156R
		LOWER WINCH IN	LOWER WINCH OUT			Top Deck Winch IN	Top Deck Winch OUT	Tail Door UP	Tail Door DOWN	Platform LEFT	Platform RIGHT
		RAMP DOWN	RAMP UP			Bottom Deck Winch IN	Bottom Deck Winch OUT	Ejector Ram OUT	Ejector Ram IN	LIFTING Platform	LOWERING Platform

		Top Winch IN	Top Winch OUT	FLOAT ON	FLOAT OFF	TO	RL			RAMP	RAMP
157L	157R	158L	158R	159L	159R	160L	160R	161L	161R	162L	162R
		Bottom Winch IN	Bottom Winch OUT	UP	DOWN	LL	RA	BED	BED	LOCKING FLAP OPEN	LOCKING FLAP CLOSED
		Bed UP	Bed DOWN	LEFT	RIGHT	LA	SS	DECK	DECK	RAMP FOLD	RAMP FOLD

Head Yoke OPEN	Head Yoke CLOSE	UP	DOWN	UNFOLD	FOLD	BAG UP	BAG DOWN				
163L	163R	164L	164R	165L	165R	166L	166R	167L	167R	168L	168R
Side Squeeze RELEASE	Side Squeeze CLOSE	Tilt UP	Tilt DOWN			BAG IN	BAG OUT			UP	DOWN
Rear Door OPEN	Rear Door CLOSE	Boom IN	Boom OUT			PAN UP	PAN DOWN			IN	OUT

		Winch IN	Winch OUT								
6F-169L	6F-169R	6F-170L	6F-170R	6F-171L	6F-171R	6F-172L	6F-172R	6F-173L	6F-173R	6F-174L	6F-174R
		Winch RIGHT	Winch LEFT								
		Bed ON	Bed OFF								

		ON	OFF			Winch OUT	Winch IN				
6F-175L	6F-175R	6F-176L	6F-176R	6F-177L	6F-177R	6F-178L	6F-178R	6F-179L	6F-179R	6F-180L	6F-180R
		OPEN	CLOSED			Tail UNLOCK	Tail LOCK				
		OPEN	CLOSED			Tail LOWER	Tail RAISE				

						Throttle SLOW	Throttle FAST				
6F-181L	6F-181R	6F-182L	6F-182R	6F-183L	6F-183R	6F-184L	6F-184R	6F-185L	6F-185R	6F-186L	6F-186R
						Clutch OFF	Clutch ON				
						Engine STOP	Engine START				

		Tail-lift UP	Tail-lift DOWN			Bumper UP	Bumper DOWN				
6F-187L	6F-187R	6F-188L	6F-188R	6F-189L	6F-189R	6F-190L	6F-190R	6F-191L	6F-191R	6F-192L	6F-192R
		Hoist UP	Hoist DOWN	RPM RPM RPM	RPM RPM RPM	ON	OFF	SP FREE SPOOL	WINCH FREE SPOOL	RPM RPM RPM	RPM RPM RPM
		Strobe Light ON/OFF	Work Light ON/OFF	ENGINE STOP		Winch	Body			ENGINE STOP	

BODY UP	BODY DOWN			BUMPER UP	BUMPER DOWN					WINCH IN	WINCH OUT
193L	193R	194L	194R	195L	195R	196L	196R	197L	197R	198L	198R
GATE OPEN	GATE CLOSED			OFF	ON					TAIL DOWN	TAIL UP
AUX 1	AUX 2			WINCH	BODY	WINCH IN	WINCH OUT			DECK FORWARD	DECK BACK
FRONT HATBOX UP	FRONT HATBOX DOWN	REAR HATBOX UP	REAR HATBOX DOWN	BED IN	BED OUT			BOOM UP	BOOM DOWN		
199L	199R	200L	200R	201L	201R	202L	202R	203L	203R	204L	204R
ROAD SIDE EXPAND	ROAD SIDE RETRACT	ROAD SIDE EXPAND	ROAD SIDE RETRACT	BED UP	BED DOWN			BOOM IN	BOOM OUT	UP	DOWN
CURB SIDE EXPAND	CURB SIDE RETRACT	CURB SIDE EXPAND	CURB SIDE RETRACT	WINCH IN	WINCH OUT			TILT UP	TILT DOWN		
		1	1					FRONT IN	FRONT OUT		
205L	205R	206L	206R	207L	207R	208L	208R	209L	209R	210L	210R
		2	2					F/S	LIGHTS		
RAMP	RAMP	3	3					REAR IN	REAR OUT		
MAIN LIFT UP	MAIN LIFT DOWN			UP LEFT	DOWN LEFT	RAISE	LOWER	DOORS OPEN	DOORS CLOSE		
211L	211R	212L	212R	213L	213R	214L	214R	215L	215R	216L	216R
NECK IN	NECK OUT			UP CNT	DOWN CNT	EXTEND	RETRACT				
FOOT EXTEND IN	FOOT EXTEND OUT			UP RIGHT	DOWN RIGHT						

Trailer Tail Door UP	Trailer Tail Door DOWN	LEFT	RIGHT								
217L	217R	218L	218R	219L	219R	220L	220R	221L	221R	222L	222R
Ejector Ram IN	Ejector Ram OUT	UP	DOWN							UP	DOWN
Cover Roll ON	Cover Roll OFF	IN	OUT								
GUARD OPEN	GUARD CLOSED	UP	DOWN			GUARD OPEN	GUARD CLOSED	GRIZZLY DUMP	REMOTE STOP		
223L	223R	224L	224R	225L	225R	226L	226R	227L	227R	228L	228R
IN	OUT	IN	OUT			IN	OUT				
RAISE	LOWER	LOCK	UNLOCK			RAISE	LOWER	FEEDER START	FEEDER STOP	ON	OFF
		FEEDER START	FEEDER STOP							TRANSFER GATE OPEN	TRANSFER GATE CLOSE
229L	229R	230L	230R	231L	231R	232L	232R	233L	233R	234L	234R
		FEEDER + FEED	FEEDER - FEED							BOTTOM AGITATION GATE OPEN	BOTTOM AGITATION GATE CLOSE
		HYDRAULIC UNIT START	HYDRAULIC UNIT STOP							TOP AGITATION GATE OPEN	TOP AGITATION GATE CLOSE
								Winch 1 IN	Winch 1 OUT	LEG	LEG
235L	235R	236L	236R	237L	237R	238L	238R	239L	239R	240L	240R
								Winch 2 IN	Winch 2 OUT		
								Both Winch IN	Both Winch OUT	LEG	LEG

